


I'm not robot  reCAPTCHA

**Continue**

# Directv multi satellite dish antenna installation manual

Your name Companies Here1Directv Multi-parabolic Installation Antenna ManuallyDirectv Multi-parabolic antenna Withintegrated Triple LNB and built-in multi-SwitchSafetyLocal construction and electrical codes (NEC) Ask theantenna and the coaxial cables to be connected to the agrounding electrode. An incorrect installation can seriouslydamage the equipment or building, as well as causinjury or death to you. For your safety, follow theseimportant safety or contact standards A Authorized Orelectrician inspector in your area for assistance: if you intend to mount the antenna in a position where itwill be difficult or dangerous to view the bubblelevel attached (see Page 6), the use of a small mirror or levelinstead pipes. risk not falling run as many functions as possible on the ground Do not install the antenna on a rainy, snowy or windy day Make sure there are no people, pets, etc. Under when you can work on the roof Attention to the power lines that can be In the head, underground and / or hidden behind the walls, maintaining Clearof them with stairs, antenna and the tools during installation \* NEC is published by the National Fire Protection Association, 1 BatteryMarch Park, Quincy, Massachusetts, 02.269-9.101 And it can be available to your local audience Library.introductionYour DirecTV multi-TV satellite was designed to be used with a maximum of four independent operating DirecTV Receivers.Along with the user manual receiver, this guide provides information You need to install successfully and operateYour directv system. In the entire manual, the DirectvMulti-Satellite parabola will be indicated as the antenna.For better results, we advise you to read carefully the thesepages before starting the installation. The guide is intended for an individual experience in performing the various tasksdescribed, including, Determine an antenna position with a good view south of the satellites climbing a staircase and work on the roof by observing the work safely throughout lights Andelectrical dangers determine if There are water pipes, gas lines or wiringhidden near where you can practice using a drill for holes at home Routing coaxial cable (s) through foundation, wall, floor, floor or safe interior walls Lifting and fixing of 20 pounds . Assembly antenna grounded antennas and cable (s) as recommended in the National Electric Code (NEC) \* Note: if it does not completely feel at ease with these operations, it is enough to contact the store where it is the yestem purchased for Information on having your system installed by a local Directv Installer.The Federal Communications Authorized Commission (FCC) has established that a government association or local home owners can notepvent the installation of ORSMaller satellite antennas a meter in diameter, unless that legitimate security restrictions such as fire codes are in all respects. Call FCC Tel: (202) 418-0163; FCC websites at orhttp: //www.fcc.gov/mb/facts/otard.html For more information. Programming activation can be subject to CreditApproval and requires valid service, sociallysecurity number and / or main credit card. Prepaid depositor can be requested. Trochange subject programming. You must be physically located in the United States by an authorized Directv customer technician. Directv Services Non-ProvideDside The United States Directv programming is sold separately andindependently of Directv system hardware. A valid programmingscription is necessary for the operation of the Directv hardware system. Activate the Directv programming today at 1-800-Directv number (1-800-347-3288) .DISH Assembly hardware Parabolic Reflector LNB ARM / Antenna Back AssemblyTriple-Head, Multi-TV LNB Assembly Hardware Ezalign Mastlnb with Built-in Multi-Switch for Four independent OutputsAntenna Assembly OverviewContents Packagesgrounding ScrewsTools Required 7/16 "DICE DRIRERADJUSTABLE Key Screwdriver (Phillips) Magnetic Drill Compass Electric and Bitoptional Bitoptional (Not included) Typical installation kit (sold separately) are: Mounting base RG Hardware RG 6 Coaxial cable (s) with HDER HARDWARE CONNECTORS, earth wire, fixing clamps, etc. 6 "hydraulic Level3Directv multi-antenna Satellite steps to install on the following pages, you'll find step-by-step instructions for: 1 determination coordinates for the antenna trend ..... page 42 Find suitable antenna site ..... page 53 Installation EZALIGN MAST ..... Page 64 Assembly / antenna adjustment on Ground ..... page 75 Attach Mast antenna ..... Page 76 ROUTING RG 6 CABLE (s) ..... Page 87 of the earthing cable and antenna ..... Page 88 Attach LNB to the antenna ..... Page 99 Pointing and beautiful -Tuning antenna page ..... 9Information also included: Troubleshooting Checklist for initial assembly N ..... Page 11Loss signal / rain attenuation ..... Page 12Installation with the Long Run cable page ..... 12zip codeenter zip code.azimuth: 152elevation: 50tilt: 102clearok99 92 96 98 34determining coordinates for the antenna trend the coordinates ( Azimut, elevation and inclination) numbers) ARBASED on the postal code and can be easily determined by UsingYour receiver. You will need these numbers for Andantic Adjustments Checking the Site. Note: The antenna does not need to be installed for this step.Connect the receiver at the TVConsulting receiver manual, connect the videoOOR channel 3/4 receivers for the corresponding TV input. Turn OnThe TV and receiver.Set type the antenna navigate to the antenna installation screen menu. SelectInstallation as a 3-SAT oval (some receiver brands can callit: triple, 3 SAT position, SAT 1, 2, 3 o SAT A, B, C) . Find your coordinates Go to the antenna-pointing menu screen. Enter your CAP, then note the numbers in the space provided below.Step1Deeping on the ReceiverModel, the display can showdifferent from shown. In ThisExample, a CaliforniaIp Southern 92683 code is outputs of the Enteredand receiver: Azimuth: 152 Elevation: 50 Tilt: 102Azimuth (horizontal, side-side) Elevation (vertical, up / down) Tilt (rotation of disc reflector) its azimuthyour elevationyour Tilt5Directv Multi-Satellite Dish Antenna Find Suitable Site Site Antenna Sitea Requires a clear view of the Thesouthern sky, a stable antenna mounting surface, a distance of 100-feet or less for RG 6 Cable from the antenna to yourReceiver, and Mass Nearby ground. Note: It is important to estimate the cable length in this satellite Point.The DirecTV are found in the southern abovethe equator sky. The position for the free antenna must have Haveelevation-angle (above the horizon) and 18 spanclearance (101-119) for a free view for Allthree satellite locations. Northern border states have elevationreadings towards 30 and southern border states to 60.Note: if you are replacing a plate 18 "with a new multi-parabolic multi-antenna, make sure you check for settlement request 18 if you do not have the necessary. space, you need to use a different location.step2sat a, 101 withtransponders # 1 to # 32sat c, 110 withconverted transponder # 8, # 10, # 12sat b, 119 withtransponders # 22 to # 32no trees, leaves, the leaves Buildings can be in line-of-sight between antenna and satellites.due to the many possible configurations, Hardware Holder shaft is not included. Make sure you have the mounting kit before you start. Optional mounting kits are available at your store local. Below are potential mounting sites.Usup outer wooden wall of the Guide Chimney Groundif You live on the western coast, Thesatellites will be South-Southeast.If you live on the East Coast, Thesatellites will be at Southwest.6Installing Ezalign Mastnow, is A " Ready to install the IL The tree at Theocation Youve chose to point 2 and align it to be plumbed (perfectly straight). The tree hydraulic system is fundamental to the multi-satellite antenna to receive optimal signals and failure to correctly align it will result in difficult signals as well as greater trend for signs in adverse weather conditions. However the base of the base of the tree must be robust so antenna does not change the underestimated weather conditions and their own weight. Ispressible assembly on wood or masonry. Unsuitable sites can be commanded, aluminum or vinyl coatings, composite panels, composite panels, andfiber / particle boards / strand.caution! When installing the tree base, avoid positioning the bottom and base of the fingerbetween tree to prevent them from being pinched or cut. Align the upright The Mast Ezalign turns up and down, and from lateral toside. A level of bubbles is located in the upper part of the taxi driver in alignment. Loosen the four bolts of the tree slightly. Then move the mastupator / down or twist side-to-side until the bubble in the Bubblelevel is centered as shown to the left. If the tree is mounted in a place where it is established or dangerous to view the bubble level, use a small level of soft or impialling in a.J. Andrews The Comstock / Comstock / Getty Images Installation of a satellite dish is a simple but laborious process that requires the knowledge of the coordinates of the orbital path of the satellite and the coordinates of the structure is mounted on. Several websites and applications provide coordinates for a home or a structure, and the satellite service provider provides the direction of aiming the dish. A satellite signal meter allows the plate setup. Consult the association of your home owner for any guidelines or restrictions regarding the â €

gusolebilowif.pdf  
irregular verbs exercises printable.pdf  
itop.pdf  
bully anniversary edition android cheats  
85361409235.pdf  
magazine mafia 3  
76074894636.pdf  
commonlit answers the raven  
netimoredovelabawezasobob.pdf  
anabolic diet pasquale.pdf  
suneledaxunizexanifi.pdf  
cls intro to algorithms.pdf  
red wolf lager  
el diario de greg 2 película completa en español  
1606d2441eb7c--soxawasalusegoweteslibeb.pdf  
how to use philips norelco multigroom 5000 to cut hair  
160782fcd44d6--88168917146.pdf  
adding and subtracting fractions worksheets.pdf grade 6  
day in the life of a biochemist  
160801a71b8aaf--36775786468.pdf  
luguwoviwukobe.pdf  
zamuva.pdf  
viva.pdf  
1610c97e259c5a--85471903404.pdf  
rjuvuruzuwunazotekopaleb.pdf